




CHANNEL FREQUENCIES ROTTERDAM

CHANNEL	FREQUENCY	CHANNEL	FREQUENCY
21	470-478 MHz	51	710-718 MHz
22	478-486 MHz	52	718-726 MHz
23	486-494 MHz	53	726-734 MHz
24	494-502 MHz	54	734-742 MHz
25	502-518 MHz	55	742-750 MHz
26	510-518 MHz	56	750-758 MHz
27	518-526 MHz	57	758-766 MHz
28	526-534 MHz	58	766-774 MHz
29	534-542 MHz	59	774-782 MHz
30	542-550 MHz	60	782-790 MHz
31	550-558 MHz	61	790-798 MHz
32	558-566 MHz	62	798-806 MHz
33	566-574 MHz	63	806-814 MHz
34	574-582 MHz	64	814-822 MHz
35	582-590 MHz	65	822-830 MHz
36	590-598 MHz	66	830-838 MHz
37	598-606 MHz	67	838-846 MHz
38	606-614 MHz	68	846-854 MHz
39	614-622 MHz	69	854-862 MHz
40	622-630 MHz		
41	630-638 MHz		
42	638-646 MHz		
43	646-654 MHz		
44	654-662 MHz		
45	662-670 MHz		
46	670-678 MHz		
47	678-686 MHz		
48	686-694 MHz		
49	694-702 MHz		
50	702-710 MHz		

	Use not allowed All equipment
	Free for use (max. 50 mW) Mic & Wireless Monitoring
	Usable with license (max. 10W) Intercom & Reportersets